# **Bearing Cup Installer**

10202



Have What It Takes

### **Safety Warning**

Read all instructions and safety warnings prior to operation. Failure to do so could result in equipment damage, personal injury or even death.

- Stay Alert! Watch what you are doing and use common sense when operating this tool.
- Inspect product for damage prior to using; do not use if product is in unsafe condition.
- Do not operate tool while under the influence of drugs, alcohol or medication.
- Always use safety equipment to prevent injuries. Approved face and eye protection must always be worn by the operator, as well as others in the work area.
- Do not overreach. Keep proper footing and balance at all times.
- Dress properly. Do not wear loose clothing or jewelry. Keep your hair, clothing and gloves away from moving parts.
- · Keep your work area clean and well lit.

## **Operating Instructions**

- Place new bearing cup against magnet side of installer.
- Insert second bearing cup into driveline.
- 3 Align installer over both bearing cups.
- 4 Turn forcing screw by hand or with impact wrench.
- 5 Both bearing cups will be pressed in at the same time.
- **6** Repeat process on two remaining bearing cups.

**Note:** Depending on driveline, tool may have to be flipped around to achieve proper bearing cup depth in order to install retaining cup.

Here at Tiger Tool, your satisfaction is our number one priority. Should you have any questions about this or any of our products, please call us at 1.800.661.4661.



# **Bearing Cup Installer**

10202



### **Parts Breakdown**



| Item No. | Part Number | Description   | Qty. |
|----------|-------------|---------------|------|
| 1        | 10202-1     | Frame         | 1    |
| 2        | 10202-2     | Forcing Screw | 1    |
| 3        | 10202-3     | Anvil         | 1    |
| 4        | 10202-4     | Magnet        | 1    |
| 5        | 10202-5     | 0-Ring        | 1    |
| 6        | 10202-6     | Ball Bearing  | 1    |