

IMPORTANT PLEASE READ FIRST!!! Supplemental Cradle Removal Manual

Removing the cradle for your new chock. This **CONDOR®** cradle is designed for easier loading and unloading of your bike. This will help in removing the cradle.



(1). After carefully removing your Condor wheel chock from the box, cut and remove the zip tie strap.



(2). Remove the Hair Cutter Pin Clip from the cradle pin and slide the cradle pin completely out from the unit.



(3). Using both hands, carefully raise the front stop channel and cradle together to an upright position.



(4). While securely holding the front-stop channel in one hand, carefully use your other hand to lift the lower portion of the cradle out and away from the v-bracket which is attached to the front-stop channel



(5). Once you have cleared the lower portion of the front-stop v-bracket with the cradle, you can now lift the cradle straight up and away from the entire unit.



Be sure to place the cradle with the extended nub that is located only on one end of the cradle facing away from the unit.



(6). Once the cradle is removed from the unit, you may now re-insert it back in the original position making sure to place it in the optimal setting required for your motorcycle.