



Star Headlight assumes no responsibility for the secure mounting of your light. It is the sole responsibility of the owner to ensure that the mirror bracket upon which this product is mounted is designed to support the weight of the light being mounted.



SINCE
1889



PROUDLY MADE IN THE USA
An ISO 9001:2008 Certified Company

Star Headlight & Lantern Co., Inc.

455 Rochester Street Avon, NY 14414


Phone: 585-226-9787 FAX: 888-478-2797




www.starheadlight.com

Mirror Mounting Brackets


274-MMB




274-MMB1S




274-MMBS




274-MMBT



274-MMBP



274-MMB1T



Star Headlight & Lantern Co., Inc.

455 Rochester Street Avon, NY 14414

Phone: 585-226-9787 FAX: 888-478-2797




www.starheadlight.com

REPRODUCTION OF THIS DOCUMENT IS PROHIBITED

The 274-MMB, 274-MMBP, 274-MMBS, and 274-MMBT are designed to mount a ½" pipe mount warning light to the truck's outside mirror assembly.


The 274-MMB1S, and 274-MMB1T are designed to mount a 1" pipe mount warning light to the truck's outside mirror assembly.

PARTS



Part #	Description	274-MMB	274-MMBP	274-MMBS	274-MMB1S	274-MMBT	274-MMB1T
A	P274-MMBP Standard L-Bracket with 0.84" Hole	1	N/A	N/A	N/A	N/A	N/A
B	P274-MMB1P Small L-Bracket with 1" Hole	N/A	1	N/A	N/A	N/A	N/A
C	P274-MMBSP Short L-Bracket with 0.84" Hole	N/A	N/A	1	N/A	N/A	N/A
D	P274-MMB1SP Short L-Bracket with 1.3" Hole	N/A	N/A	N/A	1	N/A	N/A
E	P274-MMBTTP Tall L-Bracket with 0.84" Hole	N/A	N/A	N/A	N/A	1	N/A
F	P274-MMB1TP Tall L-Bracket with 1.3" Hole	N/A	N/A	N/A	N/A	N/A	1
G	P30056-18 ½"-20 x ¾" x 1-¼" U-Bolts	2	2	2	2	2	2
H	P30019-108 ½"-20 x 1-¼" x 2-½" U-Bolts	N/A	N/A	N/A	2	2	2
I	P30096-5 ½"-20 Nylon Insert Locknuts	4	4	4	4	4	4
J	P30100-3 ½" NPT Threaded Nipple	1	N/A	1	N/A	1	N/A
K	P30019-109 1" NPT Threaded Nipple	N/A	N/A	N/A	1	N/A	1
L	P316 Reducing Coupler ¾" F to ½" M	N/A	1	N/A	N/A	N/A	N/A
M	P30019-110 Lock Nut for 1" NPT Nipple	N/A	N/A	N/A	1	N/A	1
N	P30104-1 Lock Nut for ¾" NPT Nipple	N/A	2	N/A	N/A	N/A	N/A
O	P30181-1PB 4" Threaded Pipe	N/A	1	N/A	N/A	N/A	N/A
P	P545 Fuse Holder with 5 Amp Fuse	1	1	1	1	1	1
Q	P271-18/2SJE-13 18AWG 13' Two-Conductor Cable	1	1	1	1	1	1
R	P30171-2 Grey Wire Nuts	4	4	4	4	4	4
S	P4138 4" Cable Ties	4	4	4	4	4	4

MOUNTING



- The 274-MMB series brackets may be mounted to either a horizontal or vertical stock. Attach the U-Bolts to the "L" Bracket using the nuts provided. Both applications are shown in Figure 1. The 274-MMBS, 274-MMB1S, 274-MMBT, and 274-MMB1T come with two different sets of U-Bolts. Use the larger ones for 1-¼" diameter stock and use the smaller ones for ¾" diameter stock.
- For ½" pipe mounts:** Use the NPT Threaded Nipple to attach your light to the "L" Bracket as shown in Figure 2. Insert the nipple through the "L" bracket and route your wires through it. Then screw the nipple into the threaded pipe mount in the base of your light. Use a box end wrench to tighten the nut securely.
- For 1" pipe mounts:** Secure the NPT Threaded Nipple to the "L" Bracket using the lock nut as shown in Figure 3. Route your wires through the opening and mount the base of your light to the nipple. Use a box end wrench to tighten the nipple securely.
- For ½" pipe mounts using the 4" extension pipe:** Secure the 4" NPT threaded pipe to the "L" bracket using the two lock nuts as shown in Figure 4. Then attach the reducing coupler to the pipe. Route your wires through the reducer and pipe. Then screw the reducer into the threaded pipe mount in the base of your light. Use a pliers to tighten the reducer securely.
- Connect the Gray Wire (N) to the leads from your light using the Wire Nuts (O) enclosed and route the wire appropriately to the switch (not supplied).
- Use the 5 Amp Fuse (M) to fuse your switch.
- Use the wire ties provided (P) to secure the cable to your mirror brackets.
- It is the sole responsibility of the owner to ensure the warning light is secure.**